



Dishwasher tips

For optimum cleaning and drying results – day after day!

- Remove and dispose of any large pieces of leftover food.
- There's no need to pre-rinse dishes by hand since the dishwasher has a pre-rinse programme.
- Load the dishwasher in a way that ensures all surfaces can be reached by the water jets.
- Ideally, your dishwasher should be as full as possible, but the dishes should not be touching.
- Clean the spray arms regularly in running water.
- Clean the filter system regularly in running water.
- Use a machine cleaner twice a year to remove grease and limescale residues on the walls, filter and spray arms. It will also remove stubborn dirt and grease deposits in those hard-to-reach places as well as in the pipes.
- The options Energy saving, OptiStart and partial load help create energy savings of up to 10% and can be stored permanently in the main programmes.
- Regardless of whether you use powder, tabs or gel, you should always make sure the rinse aid and salt are topped up. Salt protects the heating system from limescale while rinse aid helps dishes to dry.
- If you use tabs, make sure to activate the All in 1 function in the user settings. This helps tabs to break down even for short programmes and reduces the consumption of salt and rinse aid.
- If you only use the Eco programme, make sure to run a cycle on a hotter temperature at regular intervals (Automatic or Intensive) to keep your appliance clean and hygienic.